

IR AUTO TRACKING PTZ

product performance characteristics

Powerful smart functions:

Automatic identification PELCO D/P, HIKVISION, DAHUA etc. Various control protocol.

2400, 9600 baud rate 4800, automatic identification.

485 pro-and-con connect automatic identification.

Support the HIKVISION DVR 3D positioning function

User Manual

DC 12V/AC24V---3A

※ Read this manual before using the camera

safety announcements

1. Careful transportation

Transport, storage and installation process, we need to prevent stress, severe vibration and damage to the product immersion.

2. Be careful installation of dome camera modules

To be especially careful, light up-light down, do not force squeezing movement and the structural components, so as to avoid the dome camera trouble. For security reason, do not cover the housing is not installed electricity.

3. Power, video cables and control cables

Power cables, video cables and control cables preferable to use shielded cable and is independent of routing, can not blend together with other cables.

4. Electrical Safety

In use must comply with all electrical safety standards, the ball machine or signal transmission line should work with high-voltage equipment or cables to maintain a sufficient distance (at least 50 meters), if necessary, do a good job against lightning, surge and other safeguard procedures.

5. Cleaning

When cleaning the camera housing, please use the dry soft cloth. such as severe dirt, please use neutral cleaner gently wipe. Do not use strong or with abrasive cleaner, so as not to scratch jacket, affecting image quality.

6. Please strictly sealed to prevent liquid splashing into the ball machine, otherwise it will result in permanent damage to the device.

7. Do not use the camera when exceed the limits of temperature, humidity. Dome camera use temperature of -25 °C to 70 °C, humidity less than 90%.

8. Do not install the camera near the air-conditioned outlet.

Under such conditions, the lens would be fogging following the state of hydrometer.

- By the opening and closing air-conditioner frequently caused the high and low temperature changed.
- By the opening and closing door frequently caused the high and low temperature changed.

- Make the glasses fogging environment.
- In a room filled with smoke or dust .

9. Do not use the camera toward strong light for long time, such as the sun..

Spotlight and other light will cause screen aging. Use the camera toward to strong light for a long time, may be raised CCD of the color filter damage and loss the true color images.

Catalogue

catalogue.....	2
Chapter 1 Product summarize.....	2
1.1 product synopsis.....	2
1.2 technical parameters	3
1.3 function explain.....	4
Chapter 2 equipments' installation	6
2.1 camera's dial-up and switch setting	6
Chapter 3 Menu setting and operate	8
3.1 Basic operation	8
3.2 System OSD menu operate.....	9
3.2.1 main menu.....	10
3.2.2 menu's operation.....	10
3.2.3 <SYSTEM INFORMATION>	11
3.2.4 <ADDR SETTING>	11
3.2.5 <MOTION>.....	12
3.2.6 <SET FRAME SCAN>	13
3.2.7 CLEAR FRAME SCAN.....	14
3.2.8 PATTERN	14
3.2.9 PROGRAM PATTERN	15
3.2.10 CAMERA	16
Chapter 4 simple error and maintain.....	20
4.1 simple error exclude form	20
4.2 After Service.....	21

Chapter One Product Summarize

1.2 Technical Parameters

Model Number	Auto Tracking speed dome
Image sensor	1/4" CCD 1/3"CCD
Signal mode	PAL/NTSC
Horizontal resolution	480TVL/540TVL/650TVL
Effective pixel	PAL:976(H) x 582(V) NTSC:976(H) x 494(V)
Minimum illumination	Color to B/W, Color 0.05LUX,B/W 0.001LUX
S/N ratio	>60dB(Enhanced)
Backligh compensation	ON/OFF
White balance	Auto
Electronic shutter	1/50~1/12000s
Focus length	3. 2~115.2mm
Optical focus	22xX27/X/30X/36X/360X
Focus	manual/Auto, take high-performance DSP to realize complete digital and ultra-high speed focus function
IR distance	IR 150M
Preset	256
Patrol Track	4groups,each can record 100 actions
Cruise track	30 presets can join cruise, can setting the presets' residence time.
Other scan	Support Horizontal scan, deuce area scan, scan random
Rotation Range	Horizontal 360°unlimited rotation, Vertical 180°, auto reversal
Rotation speed	Horizontal&Vertical Min 0.01° Max 200°/s.
Communications	PELCO-D and PELCO-P
OSD	Full screen menu
Temperature Control	Optional
Power supply	DC12V/AC24V
Dimension	7 inch
Material	Aluminum shell, waterproof IP66
Wrok Environment	-25℃~+70℃ (select temperature control accessories), < 95%RH

1.3 Function Description

IR 7-inch brief intelligent high speed dome camera integration, the main function

1. Set address coding, baud rate, control protocol

Any operation commands the camera has its own objectives address coding, baud rate, control protocol, a single camera only to respond with its own address coding, baud rate, control agreement under the operation of the command. Camera address coding, baud rate, control protocol specific settings please refer to the dial-setting methods.

2. Tracking

Users can use the controls on the keyboard joystick control of the upper and lower turning left and right cameras can be used to track moving targets or moving horizon, while the focal length can be adjusted to change the perspective of the size or the target image size. In the auto-focus of the state, with the lens rotation, the camera will automatically adjust according to a rapid scene changes, instantly get a clear picture.

3. Focal length / speed automatic matching technique

Manual adjustment, the longer the focal length of the case, a reflection of high-speed ball machine makes a slight touch screen joystick may move back, resulting in data loss. Based on user-friendly design, intelligent ball according to the proximity of the focal length of the camera automatically adjusts the horizontal and vertical speed, so that manual operation is more simple and easy to track targets.

4. Auto MDIX

The operator will pull the bottom of the lens (vertical) after it is still holding down the joystick, this time the level of the lens auto-rotated 180 ° turning up immediately after the 90 °, can directly watch the back of the scene in order to achieve the full 180 ° continuous vertical surveillance.

5. Settings and call preset position

Preset function is the current state of the ball under the PTZ function of the horizontal angle, tilt angle and camera lens focal length, etc. position parameters stored in memory, you need to call these parameters can be quickly and PTZ cameras will be adjusted to that location. The operator can quickly and easily by controlling the keyboard, infrared controller, control equipment such as storage and call the preset point, the ball machine to support 256 preset points.

6. Lens Control

(1) Zoom control

Users can control the keyboard or through the ball machine to adjust the focus of the distance matrix of the host, receive the necessary panoramic images, or is a fine view.

(2) Focus Control

System default auto-focus, zoom, the camera lens will be the center of the screen features auto-focus, to maintain a clear picture; in exceptional circumstances, the user can manually focus, achieve the desired image effect.

When in manual focus state, to restore the auto-focus, as long as the sway bar can be restored remotely auto-focus. There is also a dedicated control commands can be issued or to call an arbitrary way of restoring a preset bit auto-focus.

The camera lens in the following situations will not autofocus on the camera objectives:

- a. Target is not to screen center;
- b. Targets the same time in the far and near the place;
- c. Target light objects, such as neon lighting, spotlights and other luminous objects;
- d. Target with droplets or dust behind the glass;
- e. Targets moving too fast;
- f. Large area targets, such as walls;
- g. Objectives are too dark or inherently ambiguous.

7. Aperture Control

Users can control the keyboard, manually adjust the aperture size, to obtain the required picture brightness.

8. Auto Backlight Compensation

When the backlight compensation function is open, the camera lens in the light background can be automatically targets the more the dark luminance compensation. On the bright background light adjustment, to avoid the background brightness caused by a mass of light throughout the picture, goals and not identifiable because of the darkness to gain a clear image.

9. Auto White Balance

According to the changes in ambient light, automatic adjustment, the true color reproduction.

10. Night vision function (color / monochrome conversion)

Cameras with night vision function, automatic color / monochrome conversion mode, in accordance with changes in ambient light automatic conversion CCD illumination. Such as: adequate lighting during the day due to the use of general illumination to ensure colorful images. In the night illumination can be automatically changed to black and white images show a clear interest.

11. Cruise

Can be pre-set cruise preset point, certain preset points, organized in the order required to auto-cruise in the queue, only an external command can be in an indoor speed ball set automatically according to preset points in order to provide the time interval constant movement back and forth.

12. Pattern scanning

Pattern scanning machines to run the ball through the menu, the trajectory is stored down by power-on action, free movement, alarm linkage, etc. to call the stored scan line.

13. Continuous scan

Just an external command or through a power-on action, free movement, alarm linkage, etc. to call, can make the ball machine horizontal direction to a certain speed the cycle of continuous scanning.

14. Batch Scanning

Just an external command or through a power-on action, free movement, alarm linkage, etc. to call, can make the horizontal direction the ball machine cycle of a certain speed intermittent scan.


15. Area scan

Just an external command or through a power-on action, free movement, alarm linkage, etc. to call, can make the ball machine horizontal direction to a certain speed, within the limits set by the community and from scanning.

2.1 Camera's dial-up and Switch setting

IR7-inch integrated intelligent speed dome camera is compatible with a variety of control protocols, baud rate can be adjusted to make it compatible with more of the monitoring system. In the fixed installation of ball machine before, according to the need to adjust the DIP switches to the appropriate coding, to change the baud rate of the ball machine, control protocol, address coding. If there are no special requirements, the ball machine factory default value for the address coding "1", the baud rate is set to "2400BPS", Control Protocol is set to "PELCO-D".

IR 6-inch integrated intelligent speed dome camera can be DIP switch to change the ball machine, "Baud Rate (BAUD-RATE)", "Control Protocol (PROTOCOL)" and "address coding (ADDRESS)". Ball machine movement DIP switch plans, such as:



Note: 4 DIP switches as follows: baud rate and control protocol switch

8 DIP switches as follows: Address DIP Switch

DIP switch appropriated for "ON" means "1", DIP switch appropriated for "OFF" means "0",
DIP switch on the left for the low, right is high

Baud rate and control protocol setting form:

No.	1	2	3	4	
Buad rate (BPS)			ON	OFF	2400
			OFF	ON	4800
			ON	ON	9600
Control protocol	ON	OFF			PELCO-D
	OFF	ON			PELCO-P

8-bit DIP switch is used to set the ball machine address coding. Address set binary mode can be set to a total of 256 different ball machine address coding, see coding table address.

Camera address	Coding form							
	1	2	3	4	5	6	7	8
0	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
2	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
3	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
4	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF
5	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
6	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
7	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
8	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF
9	ON	OFF	OFF	ON	OFF	OFF	OFF	OFF
10	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
11	ON	ON	OFF	ON	OFF	OFF	OFF	OFF
12	OFF	OFF	ON	ON	OFF	OFF	OFF	OFF
246	OFF	ON	ON	OFF	ON	ON	ON	ON
247	ON	ON	ON	OFF	ON	ON	ON	ON
248	OFF	OFF	OFF	ON	ON	ON	ON	ON
249	ON	OFF	OFF	ON	ON	ON	ON	ON
250	OFF	ON	OFF	ON	ON	ON	ON	ON
251	ON	ON	OFF	ON	ON	ON	ON	ON
252	OFF	OFF	ON	ON	ON	ON	ON	ON
253	ON	OFF	ON	ON	ON	ON	ON	ON
254	OFF	ON	ON	ON	ON	ON	ON	ON
255	ON	ON	ON	ON	ON	ON	ON	ON

3.1 Basic Operation

3.1.1 Power-On Self-Test

The ball machine power, the camera horizontal and vertical movement, the screen will appear system-related information, such as dome-associated system message disappears, the dome camera self-test to complete the following diagram

PTOL: AUTO COMM: AUTO ADDR: 1

Display: AUTO protocol、Buad Rate AUTO、Address code 1

3.1.2 control the camera rotating around the upper and lower

After selecting a camera, you can manually control the keyboard on the joystick up and down around the dome camera movement. The shake control joystick moves the camera, when the joystick to the right shake, the camera is also to right. Similarly, when the joystick to the left when the camera shake movement is also to the left. Rocker vertical shake when the camera also follows the appropriate action to do the vertical direction. Shake the joystick according to the diagonal direction, it can allow the camera to do the same time, horizontal and vertical movement, and direction of motion consistent with the joystick.

3.1.3 Lens Focus Control

Note: Different manufacturers keyboard preset keys are different, the keyboard manufacturer.

By controlling the keyboard on the "ZOOM-" and "ZOOM+" button to control the variable lens multiples (ie, closer, pulling away).

By controlling the keyboard on "FOCUS-" and "FOCUS+" button to control the focusing lens (camera must be set to "manual" focus or the "Auto / Manual" focus to be effective).

Note: The following situation may occur can not focus on the case

- a: are looking at target is not to screen center.
- b: At the same time observe the distant and near targets, not at the same time ensure that front and rear are clear.
- C: target for the light body, such as spotlights, car headlights and so on.
- d: target is moving too quickly or the environment too dark.

Iris control of most of the camera for automatic Iris control, and if manual control over Iris, through the keyboard on the "IRIS+" and "IRIS-" button to complete the Iris open and closed

3.1.4 presets setting

Setting Presets:

- (1) selected camera (see manual control of the keyboard);
- (2) operation Rocker, zoom button, focus button, buttons adjust the camera aperture screen;
- (3) Press the number keys + PRESET (input designated preset) to preserve the scene preset parameters.

Call preset points:

- (1) Selected camera;
- (2) Press the number keys (inputs the designated preset) + PREVIEW button, the camera immediately move to the preset position, the lens zoom, focus and Iris is also automatically change to the preset parameters; if the input is a special function preset point (see "Preset Point menu"), the dome camera will perform with special features preset point of the corresponding functions,

Presets Function form

Dial the 95 th Presets	Enter Main menu
Dial the 83 th Presets	clear all presets
Dial the 84 th Presets	use Patrol scan 1
Dial the 85 th Presets	use Patrol scan 2
Dial the 86 th Presets	use Patrol scan 3
Dial the 87 th Presets	use Patrol scan 4
Dial the 96 th Presets	360-degree gap scan
Dial the 97 th Presets	scan between two presets
Dial the 98 th Presets	presets cruise
Dial the 99 th Presets	Auto Cruise

3.2 System OSD menu operation

This section will detail the operation of OSD menu. Power is switched on, the dome camera self-test after the monitor screen will display the following information:

Control Protocol: AUTO

Serial Information: AUTO

dome camera Address: 1

Since different control keyboard on the dome camera operation method are not identical, specific operations, please contact the keyboard dealer.

1. To enter the main menu: Call 95 preset points, will enter the OSD main menu. IRIS-(aperture opening) is to identify key, IRIS + (aperture closure) is a key to exit the menu.
2. Into the other menu: up / down shake the joystick, so that the cursor is pointing to a menu, press IRIS-key, to enter the menu.
3. Function options: up / down shake the joystick, so that the cursor is pointing to a function key, according to IRIS-key, select the current function.
4. Parameters: up / down shake the joystick, select parameters, according to IRIS-key,

save the current parameters.

5. Save Settings: Press IRIS-key, save the current settings, when there is valid under the appropriate prompt.

6. Exit menu: up / down shake the joystick, so that the cursor point to the menu "EXIT" option, then IRIS + button to exit OSD menu.

7. To return to the previous one menu: up / down shake the joystick, so that the cursor menu, point to "BACK" option, then IRIS-key, to return to the previous menu level.

Notes: 1. Settings for different ball machine, ball machine displays the contents of the different power.

The following describes in detail the use of ball machine OSD menu operation.

3.2.1 Main Menu

Ball machine power and working properly, call the 95 preset points, into the main menu screen display shown in Figure 3-1.




Image 3-1 MAINMENU

Description of the contents of the main menu:

<SYSTEM INFORMATION>: Display cameras' basic informations

<ADDR SETTING>: Can setting soft dome's address.

<MOTION>: Parameters setting.

<PATTERNS>: patrol scan setting

<CAMERA>: lens setting

<CRUISE SETTING >: presets cruise setting

<ALARMS SETTING >: alarm settings

<DISPLAY SETUP> : display setting

<IR SETTING>: ir setting

RESTORE FACTORY DEFAULT: Restart lens, recover parameters as default configuration, recover factory setting.

REBOOT SYSTEM: System restart, To re-power-on reset

EXIT: exit OSD MENU

3.2.2 Menus for execute functions basic operations

1. In Figure 3-1MAINMENU the main menu, up / down shake the joystick, so that the cursor is pointing to a menu item or feature option;

2. Press IRIS-key, to enter the menu or perform a particular function

3.2.3 <SYSTEM INFORMATION> (System Information menu)

In Figure 3-1 MAINMENU the main menu, up / down shake the joystick, so that the cursor point <SYSTEM INFORMATION>, then IRIS+ key, enter Figure 3-2 System Information menu.

SYSTEM INFORMATION	
COM	2400,N,8,1
ADDRESS	1
PROTOCOL	PELCO-D
PRESETS	256
SOFTWARE VERSION	V5.2
BACK	
EXIT	

Image 3-2 SYSTEM INFORMATIO system information menu

SYSTEM INFORMATION use for check camera's current basic informations. It's function introduce as follow:

COM: Sata information, Display cameras current SATA BAUD Rate, Parity bit, data bits, stopbits of information.

ADDRESS: Dome camera's address, displays the current ball machine address coding ,0-255.

PROTOCOL: Control protocol, Displays the current ball machine communication protocol.

SOFTWARE VERSION: display current software version.

BACK: back to main menu.

EXIT: exit menu setting.

Note: The System Information menu, the various elements in this menu can not be changed.

3.2.4 <ADDR SETTING> (Address Settings menu)

In Figure 3-1 MAINMENU the main menu, up / down shake the joystick, so that the cursor point <ADDR SETTING>, then IRIS+ key, enter the Figure 3-3 ADDR SETTING address settings menu.

ADDR SETTING	
ADDR TYPE	HARD
ADDR SOFT	3
ADDR HARD	1
BACK	
EXIT	

Image 3-3 ADDR SETTING address menu setting

In image 3-3 ADDR SETTING Address Settings menu, up / down shaking rocker, ADDR TYPE (address type) value can select HARD (hard address) and SOFT (soft address) in the system installation is complete, you can direct the remote Set ball machine address. ADDR SOFT: In the ADDR TYPE selection SOFT, you can directly determine the ball machine address.

Attention: soft address and hard address setting must not be confused, or the ball machine out of control, everything is set to be effective needs to be restarted

3.2.5 <MOTION> (PTZ settings)

In Figure 3-1MAINMENU the main menu, up / down shake the joystick, so that the cursor point <MOTION>, then IRIS+ key, enter Figure 3-4 <MOTION> menu.




Image 3-4<MOTION>

Menu clarification:

<MOTION> Menu is used to set PTZ parameters such as movement and orientation angles.

<SET FRAME SCAN>: Is used to set the region to scan the left and right pole

POWER UP: On the power to set the menu, on the power to set the ball machine is used to set the power, no control instructions received prior to the implementation of the action.

Parameters as follows:

NONE(no): Does not perform any action.

CRUISE(Preset Point cruise): implementation of the preset points, cruise movements.

AUTO SCAN(Continuous scan): implementation of a continuous scanning motion.

RANDOM SCAN(Intermittent scanning): the implementation of intermittent scanning motion.

FRAME SCAN(Area scan): implementation of the regional scan action (regional scanning range was set after the valid).

PRESET 1(Preset point 1): to reach No. 1 preset points.

PRESET 8(Preset point 8): reach the 8 preset points.

PATTERN 1(Pattern scan 1): implementation of the pattern scanning line 1

PATTERN 2(Pattern scan 2): implementation of the pattern scan line 2.

PATTERN 3 (pattern scan 3): implementation of the pattern scanning line 3.

PATTERN 4(Pattern scan 4): implementation of the pattern scan line 4.

PARK TIME: The time required for the implementation of free movement settings.

Parameter range of 15s, 1 minute, 2 minutes ... 59 minutes, 1 hour ... 12 hours.

PARK ACTION: Exit ball machine menu, in the idle time, the ball machine does not receive any instruction of the implementation of the action.

Free action parameter description:

NONE(no): Does not perform any action.

REPEAT LAST(Recovery last action): automatically restore to the most recent action.
CRUISE(Preset Point cruise): implementation of the pre-cruise-point action (preset point is set after the valid).

AUTO SCAN(Continuous scan): implementation of a continuous scanning motion.

RANDOM SCAN(Intermittent scanning): the implementation of intermittent scanning motion.

FRAME SCAN(Area scan): implementation of the regional scan action (regional scanning range was set after the valid).

PRESET 1(Preset point 1): to reach No. 1 preset points.

PRESET 8(Preset point 8): reach the 8 preset points.

PATTERN 1(Pattern scan 1): implementation of the pattern scanning line 1.

PATTERN 2(Pattern scan 2): implementation of the pattern scan line 2.

PATTERN 3(Pattern scan 3): implementation of the pattern scanning line 3.

PATTERN 4(Pattern scan 4): implementation of the pattern scan line 4.

FRAME SCAN SPEED : Settings area scanning speed, set the ball machine area scanning speed. Parameter range 1 ~ 32.

BACK: Return to Main Menu

EXIT: exit the menu setting

Function parameters to set the basic operations:

1. Image 3-4<MOTION>(PTZ settings) menu, up / down shake the joystick, so that the cursor is pointing to the menu features an option;
2. Press IRIS+ key;
3. up/down Shaking rocker, select the parameters you need;
4. Again press Press IRIS+ key.

3.2.6 <SET FRAME SCAN>(setting area scan)

Settings area scanning range, specific operations are as follows:

In Figure 3-4 <MOTION> (PTZ settings) menu, up / down shake the joystick, so that the cursor point <SET FRAME SCAN>; by IRIS+ key, enter the following diagram:

FRAME SCAN
SET SCAN POSITION
CLEAR FRAME SCAN
FRAME SCAN SPEED 1
BACK
EXIT

Image 3-4-1FRAME SCAN setting area scan

<SET FRAME SCAN> Menu is used to set the scope of the regional scan.

<SET SCAN POSITION>: Set the scope of the regional area scan

<CLEAR FRAME SCAN>: Clear area scan range

BACK: Back to a Menu

EXIT:exit the menu

3.2.7 SET SCAN POSITION(setting area scan)

In Figure 3-4-1 FRAME SCAN Settings area scan the menu, up / down shake the joystick, so that the cursor point <SET SCAN POSITION>; by IRIS+ key, enter the next figure

SET FFRAME SCAN LEFT LIMIT POSITION IRIS OPEN TO CONTINUE

Image 3-4-2 to set the left limit position of regional scanning

Shaking rocker, select the area scan the left limit position; by IRIS+ key, to confirm the current position is the left limit position, and enter the following diagram:

SET FFRAME SCAN RIGHT LIMIT POSITION IRIS OPEN TO CONTINUE

Image 3-4-3 to set the right limit positions of regional scanning

Shaking rocker, choose the right limit of area scan position; by IRIS+ key, to confirm the current position is the right limit position, save the extreme left position and right limit positions, and return to Figure 3-4-1.

3.2.8 CLEAR FRAME SCAN (Clear area scan location)

In Figure 3-4-1 FRAME SCAN Settings area scan the menu, up / down shake the joystick, so that the cursor point <CLEAR FRAME SCAN>; by IRIS+ key, enter the following diagram:

CLEAR FFRAME SCAN IRIS OPEN TO CONTINUE
--

Image 3-5. CAMERA settings menu

By IRIS+ key, clear the position of the left and right limits of extreme position and return to Figure 3-4-1.

3.2.9<PATTERN>(Pattern scan)

In Figure 3-4 MAINMENU the main menu, up / down shake the joystick, so that the cursor point <PATTERN> (pattern scan), then IRIS-key, enter the pattern in Figure 3-5 Scan Menu

PATTERNS	
PATTERN NUMBER	1
PROGRAM PATTERN	
CLEAR CURRENT PATTERN	
CLEAR ALL PATTERN	
BACK	
EXIT	

Image 3-5-1 Pattern scan menu

Scan pattern is used to set and clear the pattern scan lines.

Synchronized Scan ID: Select the pattern scan number. Number range 1 ~ 4. To do the following:

1. In Figure 3-5 <PATTERN> (pattern scan) menu, up / down shake the joystick, so

that the cursor point PATTERN NUMBER (pattern scan) number;

2. Press IRIS+ key;

3. Up / down shake the joystick, select the pattern scan number;

4. Press IRIS+ key

3.2.10 <PROGRAM PATTERN> (pattern scan settings)

"Synchronized scan settings" is used to set the pattern scan lines. To do the following:

1. Select pattern scan number;

2. Pattern in Figure 3-5 Scanning the menu, up / down shake the joystick, so that the cursor point <PROGRAM PATTERN>;

3. Press IRIS+ key, enter the following diagram:

PROGRAM PATTERN MOVE THE CAMERA TO THE STARTING POSITION IRIS OPEN TO CONTINUE

Image 3-5-2 PROGRAM PATTERN settings menu

4. Shake joystick to determine the starting position of the scan pattern;

5. By IRIS+ key, will enter the following diagram:

PATTERN STORAGE USED<PCT> 1

Image 3-5-3 PATTERN settings menu

6. Sway away from pole, edit, scan lines and movement, a movement began to record from up to 100 moves, according to IRIS+ key, save the settings, return to Figure 3-5;

3.2.11 CAMERA (Lens) settings menu (Different lens with different parameters)

In Figure 3-1 the main menu, up / down shake the joystick, so that the cursor point <CAMERA>, then IRIS+ key, enter the camera menu controls, enter the settings menu

Figure 3-6 CAMERA

Languages	Chinese/English
Multiples Display	ON/OFF
AGC	180
Blighlight compensate	ON/OFF
Shutter setting	AUTO
Focus setting	AUTO
Brightness setting	110
Sharpness Setting	013
Day& night switch	AUTO
Negative Set	OFF
Lens Set	OFF
Default Set	OFF

Image 3-6CAMERA settings menu

Function parameters to set the basic operations:

1. The lens in Figure 3-6 to set menu, up / down shake the joystick, so that the cursor is pointing to the menu options for a particular function;
2. Press IRIS+ key;
3. Up / down shake the joystick, select the parameters you need;
4. Then IRIS+ key.

3.2.12 CRUISE (preset points, cruise settings) menu

In Figure 3-1MAINMENU the main menu, up / down shake the joystick, so that the cursor point <CRUISE>, then IRIS+ key, enter the preset point of Figure 3-7 CRUISE cruise settings menu.

CRUISE SETTING	
DWELL TIME <SECS>	6
PRESET LIST	1
1 ON 0 OFF	
1234567890 <PRESET1-10>	
1111111111	
BACK	
EXIT	

Image 3-7CRUISE preset point setting menu

Preset point cruise is used to automatically set the camera preset point of scan lines. To do the following:

1. In Figure 3-7 <CRUISE> (preset points, cruise settings) menu, up / down shake the joystick, so that the cursor point to DWELL TIME [SECS] (pre-cruise waiting time between points), according to IRIS+ key, on the up / down shaking rocker, select the waiting time, according to IRIS+ key.
2. Then, up / down shake the joystick, so that the cursor points to PRESET LIST (pre-cruise-point list), according to IRIS+ key, up / down shake the joystick, choose to participate in pre-cruise-point page, a total of 30 presets can be point involved in cruise, each page you can select 10 preset points, a total of 33 pages, the corresponding parameters 1,2,3, according to IRIS+ button to confirm.
3. Then, up / down shake the joystick, so that the cursor points to PRESET LIST (pre-cruise-point list), according to IRIS+ key, up / down shake the joystick, choose to participate in pre-cruise-point page, a total of 30 presets can be point involved in cruise, each page can select 10 preset points, a total of 3, the corresponding parameters for the 1,2,3, according to IRIS-button to confirm.
4. Then, up / down shake the joystick, so that the cursor point to 1234567890 1111111111, left / right shake the joystick, choose to participate in the pre-cruise point, the corresponding parameters for the 0,1 by IRIS+ key changes to one of choice, 0 is skipped.
5. Shake up / down joystick, select the BACK / EXIT, to save the settings, return to

3.2.13 ALARMS SETTING

Alarm setting	
Alarm input 1 action	NONE
Alarm input 2 action	NONE
Alarm input 3 action	NONE
Alarm input 4 action	NONE
Return	
BACK	

Image 3.8 Alarm setting>

Alarm linkage menu: used to install alarm action

Parameters stated below:

No: don't perform any action.

Preset point cruise: executive preset point cruise action.

Scanned continuously: executive scanned continuously moves.

Intermittent scanning: executive intermittent scanning action.

Regional scanning: executive regional scanning action (regional scanning ranges were after setting a valid).

Preset point 31 (only in alarm set to 1) : arrive 31st preset points

Preset points only in 32 (2) : alarm Settings reached 32, preset points

Preset point 33 (only in alarm Settings and 3) : reached 33 preset points

Preset point 34 (only in alarm Settings 4) : reach 34, preset points

Track scan 1: execution trace scan line 1.

Track scan 2: execution trace scan line 2.

Track scanning 3: execution trace scan line 3.

Track scanning 4: execution trace scan line 4.

Return: return to the main menu.

Exit: quit menu Settings.

Note: the ball with alarm linkage function machine does.

3.2.14 DISPLAY SETUP

Display information set	
Preset point title	on
Amplification factor	on
Vertical and horizontal Angle	on
Brightness values	off
Infrared components	off
Return	
Back	

3.9Display Settings: used to install monitors displayed project.

<Preset point title>: Used to set in the calling preset point, on the monitor preset point of indicates whether or not the serial number, open to show, close to not display.

<Amplification factor >: Magnification shows, open for displaying, close to not display.

<Vertical and horizontal Angle>: Vertical and horizontal Angle shows, open for displaying, close to not display.

<Brightness values >: Radial brightness values shows, open to show, close to not display.

<Infrared components >: Display the infrared components, open to show, close to not display.

Return: return to the main menu.

Exit: quit menu Settings.

3.2.15 IR SETTING

On the picture 3.7 SPECIAL_FUNC MENU , up/down shake the joystick , make the cursor point to < IR SYSTEM SETUP> ,press IRIS+ ,enter SPECIAL_FUNC MENU show you as below

IR SETTING	
IR MODE	AUTO
IR ON SENS	170
IR OFF SENS	220
BACK	
EXIT	

Image 4-0 IR SYSTEM SETUP

< IR SYTEM SETUP > menu is used to set IR mode, functions description as below;

IR MODE ; ON/OFF/AUTO: 。

IR ON SENSitivity : , 180 ~ 255 default 250。

IR OFF SENSitivity : 120 ~ 255 default 240。

RETURN 。

CURRENT LEVEL:。

<IR system setting>is used to set IR mode. Functions operate as below;

1. On the menu<IR SYSTEM SETUP>,up/down shake the joystick,make the cursor point at IR MODE, press IRIS+/ IRIS+ or left/right to shake the joystick choosing your need mode. Press again IRIS+

2. up/ down shake the joystick, make the cursor point at IR ON SENS,press IRIS+/ IRIS+ or left/right to shake the joystick choosing the parameters. Infrared open sensitivity is according to installation site environment adjusting mode, with normal environment system is default values

3up/down to shake the joystick, make the cursor point at IR OFF SENS,press or left/right to shake the joystick choosing parameters.infrared off sensitivity is according to installation site environment adjusting mode, with normal environment system is default values.

3.2.16 MOTION TRACKING SETTING

Motion Tracking Function:

1.Cruise Tracking : User can preset to some Preset number,then call NO.97 to preview to start Cruise Motion Tracking (Preset point Cruise).

During Cruise Preset ,there have dynamic goal, the ball machine will automatically start Motion tracking function. If No Dynamic target, the ball machine will cruise as conventional preset point cruise. This feature can be preset to 20 preset points, and each preset can participate in the same cruise.

2.Preset Tracking: User can choose different object place,Set presets,Call this preset, The ball machine will immediately polarization to this preset object and start to Auto tracking function.This feature can be preset to 7 preset points(From No.63 to No.69), For example ,When have been Preset one place as object of No.63 Preset, Preview No.63. the ball machine in which position,it will immediately to No.63 Preset and start to auto tracking function.

Ball machine in which the location, are immediately to 63 preset position, and automatically open the track.

3. Directly Start Auto Tracking:Call No.80 Preset,Manual to start Auto tracking function.

Eneter Auto Tracking OSD:

No.95 Preview,Enter OSD menu,move Joystick,Select Auto Tracking Setting,Then press IRIS enter then exit OSD.

	Auto Tracking Setting		
Auto	Magnification linkage	10	Tracking Setting
	Target size	Middle	
Auto	Sensitivity	Middle	Tracking Setting OSD:
	Tracking time	Auto	
	Waiting time:	15sec	
	Restore the default		
	Return		
	Exit		

OSD Detail

Magnification linkage:

2 modes: One is CLOSED MODE, the other one is ZOOM MODE (1x zoom~ 20x zoom), Start CLOSED MODE, the ball machine will stay the current zoom station to auto tracking, the ball machine camera lens won't zoom+ or zoom- according to the distance of target object.

Start ZOOM MODE, meaning the zoom according to auto tracking target, based on target position to change the max zoom camera lens. For example, if choose No.1, it meaning no matter the target in which position, camera lens zoom will be stay in Zoom No.1 status. If choose No.5, it meaning no matter the target in which position, camera lens zoom will be stay from 1x zoom to 5x zoom. (It depends on user required to setting)

Magnification linkage minimum to set on 1x zoom, normal camera lens will be max for 20x zoom, Sony, SAMSUNG etc top brand camera lens will be support to max zoom. For example, Sony 26x, then Magnification linkage support set from 1x zoom ~26x zoom, The Default will 10x zoom.

Target Size:

It meaning that tracking moving target will be display on screen size. Note: It is not related with actual target size. Its chosen can be (Small, Middle, Large) Select "Middle". Start Auto tracking mode,

Whether the moving targets to judge the standard moving object image monitoring screen in the proportion of the size of the target size for (small, medium, large) corresponding to the moving object image display on the monitor screen, the proportion is greater than or equal to 1/7, 1/6, 1/5, only to achieve this ratio, the ball machine will determine the monitor screen moving targets.

Sensitivity:

According to the action of the moving target which display on the monitor screen to make the magnitude of the judgment. Points "Small", "Middle", "Large" three options of default "

Tracking Time :

2 Modes :One is AUTO ,the other one is TIME SELECT.

Under AUTO mode,The tracking function will be continuous to tracking if the target object didn't lost.

Under TIME SELECT mode,user can choose tracking time to tracking ,the ball machine will be stopped tracking if time is ended.After 5 seconds,the ball machine will be continue to perform the original action.For example,the ball machine is acting Cruise tracking ,once have the moving object,if tracking time is 30sec,it will be stopped tracking if time is ended.after 5seconds,it will continue to perform Cruise Tracking.Time Tracking can be set : 30sec,40sec,50sec,1min,2min,...6min.

When the ball machine is under Tracking status,the ball machine will be perform that action of the Target object if target object lost.This action is based on the operation before lost object.For example,the ball machine perform Cruise Tracking, After the Waiting Time ended if the target object lost,the ball machine will be continue to perform CRUISE TRACKING;If the ball machine perform PRESET TRACKING,After the Waiting Time end if the target object lost,the ball machine will be continue to perform PRESET TRACKING.(No.63 ~No.69 Presets) If the ball machine perform Directly auto start tracking,after Waiting time is ended if the target object lost,the ball machine will be return back to No.1 Preset and continue to perform Tracking status.If don't have No.1 Preset,the ball machine will be stopped at the current position and keep Tracking status after Waiting time is ended.

Waiting Time:

It meaning that under the Tracking Status,the ball machine will be perform the target object of action's waiting time if target lost.Time waiting time can be: 5sec,10sec,15sec,20sec....40sec.

Restore the default:Select it press IRIS botton confirmed ,The Tracking setting will be return to DEFAULT setting status.

Return: Select it press IRIS botton confirmed,It will return to the ball machine MAIN MENU.

EXIT: Select it press IRIS botton confirmed it,it will exit to the ball machine MAIN MEN.

Tracking place noted :

Once user set the Pan Setting for standby action and standby action time,when start Auto Tracking ,the Waiting time have to be shorter than Standby Action time. If the Waiting time longer or same as Standby Action's time when start Auto tracking ,the ball machine will be perform Standby Action first if target object lost.For example ,Standby Action set for Cruise Scan,standby time set for 15sec,Set Waiting Time for 20sec,when the ball machine start auto tracking,the ball machine will be perform Cruise Scan after 15sec if target object lost.It won't perform the action of target object any more.

Chapter 4. simple troubleshooting and maintenance4.1

Simple Troubleshooting Table

Failure	Possible Cause	Solutions
Electricity without action, no images, light does not shine.	Connected the wrong power cord	Corrections
	Power supply is damaged	replace
	Bad fuse	replace
	Power cord connection is bad	Exclusion
Power are self-test, there are images, not control	IR uniform ball address code, the baud rate setting does not	To re-set the high-speed dome address code and baud rate
	Wrong protocol	corrections
	RS485 line reversed or open	Check wiring RS485 control line
Unable to complete self-test, there are images associated with motor tweet sound	Mechanical failure	Maintenance
	Camera Tilt	Straightened
	Power is not enough	Replacement to meet the requirements of the power supply, it is best to power the ball on the near-infrared uniform
Image instability	Video line connection is bad	Exclusion
	Power is not enough	replace
Blur	Manual focus on the state	Operation of any infrared uniform ball or call a preset point
IR control of a uniform-speed ball non-stop or delay	Power is not enough high-speed Dome	Replacement to meet the requirements of the power supply, it is best to power on the high-speed ball in the vicinity
	Check control of the most distant high-speed ball match whether to join the resistance	The most far away from the control of the ball-type cameras by adding matching resistor
	Far from 485 the signal attenuation	Bold Line of Control
	Converter 485 is not enough driving force	Replacement of a source converter

4.2 After Service

Dear users, in order to ensure the full enjoyment of your services, please read the following products and services charter.

(1) Protruly company supply the speed dome camera of limited warranty and lifetime maintenance services

1. The warranty period from the date of sale for 12 months, in the warranty period, you will enjoy the product free service, delivered or sent by the user (improper use, man-made causes of failure or an irresistible fault do not belong to the scope of the warranty).

2. After 12 month limited free repairing duration, the products will absorb life time repair with payable services.

(2) Speed dome camera repair time.

1. Since the customer send the product to the Protruly, 24-hour service.

1. 2. Please advise the related contact first, then return the product to our company. Otherwise, the product not timely maintenance

Product Warranty Cards

Under this product warranty description to repair the goods. Note that every case of normal use the product itself due to quality problems caused by failures in the warranty period will be given free maintenance.
--

Warranty Description:

1. This product is free of charge warranty period of one year, during the warranty period any product quality problems occur, so doing the warranty card for free (non-human damage), life-long maintenance.

2. A result of improper use or other reasons as well as the failure of products outside the warranty period can be so doing card repair, free of maintenance, only the income component costs.

3. Product required maintenance should be a copy of this card and the invoice with the product delivery of the Company or the local special maintenance department.

4. Secretly open the machine casing, tearing up letters labeling, according to the provisions of collecting maintenance fees and components and other expenses.

5. Does not accept any modification or installation of other functions due to failure after the

machine.

The following conditions will not be free of charge Warranty:

1. Due to normal wear and tear caused by periodic inspection, maintenance, repair or replacement parts.
2. As the fall, extrusion, soaking, damp, and other man-made damage.
3. Because of flood, fire, lightning and other natural disasters or force majeure of the factors that damage.
4. By non-authorized repair centers repair the machine off.
5. Listed above, if changes to the relevant provisions shall prevail.

Model No	
Manufacturing No	
Delivery Date	

Company Name	
Contact person	
Company Address	
Company Tell No	

Maintenance Date	Fault conditions	Maintenance sites	Maintenance result

remark : _____

Certification of the product



